

Frei empfangbare und HD+ TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
HD	Arte HD	frei	K 39	618,0 MHz
HD	Das Erste HD	frei	K 39	618,0 MHz
HD	SWR FS BW HD	frei	K 39	618,0 MHz
HD	SWR FS Rheinland-Pfalz HD	frei	K 39	618,0 MHz
HD	Bayerisches FS Nord HD	frei	K 55	746,0 MHz
HD	Bayerisches FS Süd HD	frei	K 55	746,0 MHz
HD	NDR FS Hamburg HD	frei	K 55	746,0 MHz
HD	NDR FS Mecklenb.-Vorp. HD	frei	K 55	746,0 MHz
HD	NDR FS Niedersachsen HD	frei	K 55	746,0 MHz
HD	NDR FS Schleswig-Holst.HD	frei	K 55	746,0 MHz
HD	Phoenix HD	frei	K 55	746,0 MHz
HD	ZDF HD	frei	K 41	634,0 MHz
HD	ZDF neo HD	frei	K 41	634,0 MHz
HD	3sat HD	frei	K 48	690,0 MHz
HD	KIKA HD	frei	K 48	690,0 MHz
HD	ZDF info HD	frei	K 48	690,0 MHz
HD	One HD	frei	K 50	706,0 MHz
HD	Eins Plus HD	frei	K 50	706,0 MHz
HD	SR Fernsehen HD	frei	K 50	706,0 MHz
HD	HR Fernsehen HD	frei	K 51	714,0 MHz
HD	MDR Thüringen HD	frei	K 51	714,0 MHz
HD	MDR Sachsen-Anhalt HD	frei	K 51	714,0 MHz
HD	MDR Sachsen HD	frei	K 51	714,0 MHz
HD	RBB Berlin HD	frei	K 51	714,0 MHz
HD	RBB Brandenburg HD	frei	K 51	714,0 MHz
HD	WDR FS Köln HD	frei	K 52	722,0 MHz
HD	Servus TV Dtl. HD	frei	K 53	730,0 MHz
HD	Mediaspar TV HD	frei	S 22	314,0 MHz
HD	QVC Beauty&Style HD	frei	S 22	314,0 MHz
HD	Channel 21 HD	frei	S 22	314,0 MHz
HD	Zee One HD	frei	S 22	314,0 MHz
HD	Fashion 4K	frei	S 23	322,0 MHz
HD	Sky Info	frei	S 35	418,0 MHz
HD	1-2-3 TV HD	frei	K 34	578,0 MHz
HD	HSE 24 Extra HD	frei	K 34	578,0 MHz
HD	QVC Plus HD	frei	K 34	578,0 MHz
HD	Anixe HD	frei	K 35	586,0 MHz
HD	HSE 24 HD	frei	K 35	586,0 MHz
HD	QVC HD	frei	K 35	586,0 MHz
HD	Juwelo TV HD	frei	K 38	610,0 MHz
HD	Pearl TV HD	frei	K 38	610,0 MHz
HD	Sonnenklar TV HD	frei	K 38	610,0 MHz
HD	N-TV HD	HD+	K 36	594,0 MHz
HD	RTL 2 HD	HD+	K 36	594,0 MHz
HD	RTL HD	HD+	K 36	594,0 MHz
HD	VOX HD	HD+	K 36	594,0 MHz
HD	Kabel Eins HD	HD+	K 37	602,0 MHz
HD	Pro Sieben HD	HD+	K 37	602,0 MHz
HD	Pro Sieben Maxx HD	HD+	K 37	602,0 MHz
HD	Sat. 1 HD	HD+	K 37	602,0 MHz
HD	Sixx HD	HD+	K 37	602,0 MHz
HD	Tele 5 HD	HD+	K 38	610,0 MHz
HD	DMAX Deutschland HD	HD+	K 38	610,0 MHz
HD	Sport 1 HD	HD+	K 35	578,0 MHz
HD	MTV Germany HD	HD+	S 22	314,0 MHz
HD	TLC Germany HD	HD+	S 22	314,0 MHz
HD	Sat1 Gold HD	HD+	S 23	322,0 MHz
HD	RTL Nitro HD	HD+	K 33	570,0 MHz

Pay-TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
HD	AXN Deutschland HD	sky	K 26	514,0 MHz
HD	Blue Movie HD	sky	S 26	346,0 MHz
HD	Boomerang Deutschland HD	sky	S 26	346,0 MHz
HD	Cartoon Network Deutschland HD	sky	S 26	346,0 MHz
HD	Discovery HD Deutschland	sky	S 41	466,0 MHz
HD	Disney Cinemagic Deutschland HD	sky	S 40	458,0 MHz
HD	Disney Junior Deutschland HD	sky	S 34	410,0 MHz
HD	E! Deutschland HD	sky	S 26	346,0 MHz
HD	Eurosport 2 Germany HD	sky	S 35	418,0 MHz
HD	Eurosport 360 HD 4	sky	S 39	450,0 MHz
HD	Eurosport 360 HD6	sky	S 26	346,0 MHz
HD	Eurosport 360 HD7	sky	S 26	346,0 MHz
HD	Eurosport 360 HD9	sky	S 26	346,0 MHz
HD	Eurosport HD	sky	S 39	450,0 MHz
HD	Fox Deutschland HD	sky	K 26	514,0 MHz
HD	History HD Deutschland	sky	S 39	450,0 MHz
HD	MGM HD Deutschland	sky	K 42	642,0 MHz
HD	Nat Geo Channel Deutschland HD	sky	S 40	458,0 MHz
HD	Nat Geo Wild Europe HD	sky	S 41	466,0 MHz
HD	RTL Crime Deutschland	sky	S 35	418,0 MHz
HD	Sky 3D HD	sky	K 26	514,0 MHz
HD	Sky Action HD	sky	S 39	450,0 MHz
HD	Sky Atlantic +1 HD	sky	S 34	410,0 MHz
HD	Sky Atlantic HD	sky	S 40	458,0 MHz
HD	Sky Atlantic HD Deutschland	sky	S 40	458,0 MHz
HD	Sky Bundesliga 1 HD	sky	K 42	642,0 MHz
HD	Sky Bundesliga 10 HD	sky	S 26	346,0 MHz
HD	Sky Bundesliga 2 HD	sky	S 41	466,0 MHz
HD	Sky Bundesliga 3 HD	sky	S 40	458,0 MHz
HD	Sky Bundesliga 4 HD	sky	K 42	642,0 MHz
HD	Sky Bundesliga 5 HD	sky	S 39	450,0 MHz
HD	Sky Bundesliga 6 HD	sky	K 26	514,0 MHz
HD	Sky Bundesliga 8 HD	sky	S 26	346,0 MHz
HD	Sky Bundesliga 9 HD	sky	K 26	514,0 MHz
HD	Sky Cinema +1 HD	sky	S 34	410,0 MHz
HD	Sky Cinema +24 HD	sky	S 34	410,0 MHz
HD	Sky Cinema HD	sky	S 41	466,0 MHz
HD	Sky HD FanZone	sky	K 26	514,0 MHz
HD	Sky Hits HD	sky	K 42	642,0 MHz
HD	Sky Select HD	sky	S 26	346,0 MHz
HD	Sky Sport 10 HD	sky	K 26	514,0 MHz
HD	Sky Sport 11 HD	sky	S 26	346,0 MHz
HD	Sky Sport 3 HD	sky	S 41	466,0 MHz
HD	Sky Sport 4 HD	sky	S 40	458,0 MHz
HD	Sky Sport 5 HD	sky	K 42	642,0 MHz
HD	Sky Sport 6 HD	sky	S 39	450,0 MHz
HD	Sky Sport 7 HD	sky	K 26	514,0 MHz
HD	Sky Sport 8 HD	sky	S 26	346,0 MHz
HD	Sky Sport 9 HD	sky	S 26	346,0 MHz
HD	Sky Sport Austria	sky	S 35	418,0 MHz
HD	Sky Sport HD 1	sky	S 41	466,0 MHz
HD	Sky Sport HD 2	sky	S 40	458,0 MHz
HD	Sky Sport News HD	sky	K 42	642,0 MHz
HD	Spiegel Geschichte HD	sky	S 34	410,0 MHz
HD	Sport 1+ HD	sky	S 39	450,0 MHz
HD	Sport1 US HD	sky	K 26	514,0 MHz
HD	Syfy Deutschland HD	sky	K 42	642,0 MHz
HD	TNT Glitz HD	sky	S 26	346,0 MHz

Radio-Sender				
Radio Art	Sender	Kanal	Frequenz	
Radio	1 Live	frei		S 24
Radio	1 Live diggi	frei		S 24
Radio	Antenne Brandenburg Potsdam	frei		S 24
Radio	B5 aktuell	frei		S 24
Radio	B5 plus	frei		S 24
Radio	Bayern 1	frei		S 24
Radio	Bayern 2	frei		S 24
Radio	Bayern 3	frei		S 24
Radio	Bayern Plus	frei		S 24
Radio	BR Heimat	frei		S 24
Radio	BR Klassik	frei		S 24
Radio	BR Puls	frei		S 24
Radio	Bremen Eins	frei		S 24
Radio	Bremen Vier	frei		S 24
Radio	Das Ding	frei		S 24
Radio	Fritz	frei		S 24
Radio	Funkhaus Europa	frei		S 24
Radio	HR 1	frei		S 24
Radio	HR 2 Kultur	frei		S 24
Radio	HR 3	frei		S 24
Radio	HR 4 Rhein-Main	frei		S 24
Radio	HR Info	frei		S 24
Radio	InfoRadio	frei		S 24
Radio	Kiraka	frei		S 24
Radio	Kulturradio	frei		S 24
Radio	MDR 1 Radio Sachsen	frei		S 24
Radio	MDR Figaro	frei		S 24
Radio	MDR Info	frei		S 24
Radio	MDR Jump	frei		S 24
Radio	MDR Klassik	frei		S 24
Radio	MDR Radio Sachsen-A.	frei		S 24
Radio	MDR Sputnik	frei		S 24
Radio	MDR Thüringen	frei		S 24
Radio	NDR 1 Niedersachsen	frei		S 24
Radio	NDR 1 Radio MV	frei		S 24
Radio	NDR 1 Welle Nord	frei		S 24
Radio	NDR 2	frei		S 24
Radio	NDR 90.3	frei		S 24
Radio	NDR Blue	frei		S 24
Radio	NDR Info	frei		S 24
Radio	NDR Info Spezial	frei		S 24
Radio	NDR Kultur	frei		S 24
Radio	N-Joy	frei		S 24
Radio	NorthwestRadio	frei		S 24
Radio	Radio Berlin 88.8	frei		S 24
Radio	Radio Eins Potsdam	frei		S 24
Radio	SR 1 Europawelle	frei		S 24
Radio	SR 2 KulturRadio	frei		S 24
Radio	SR 3 Saarlandwelle	frei		S 24
Radio	SWR 1 Baden-Württemberg	frei		S 24
Radio	SWR 1 Rheinland-Pfalz	frei		S 24
Radio	SWR 2 Baden-Württemberg	frei		S 24
Radio	SWR 3 Baden-Kurpfalz	frei		S 24
Radio	SWR 4 BW Stuttgart	frei		S 24
Radio	SWR 4 Rheinland-Pfalz Mainz	frei		S 24
Radio	SWR info	frei		S 24
Radio	WDR 2 Rheinland	frei		S 24
Radio	WDR 3	frei		S 24

Frei empfangbare und HD+ TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
HD	Super RTL Dtl. HD	HD+	K 33	570,0 MHz
HD	N 24 HD	HD+	K 35	586,0 MHz
HD	Nickelodeon HD	HD+	K 35	586,0 MHz
HD	Deluxe Music HD	Sky/HD+	K 34	578,0 MHz
HD	Disney Channel HD Germany	Sky/HD+	K 36	578,0 MHz
SD	ARD Alpha	frei	S 24	330,0 MHz
SD	SR FS	frei	S 24	330,0 MHz
SD	3sat	frei	S 25	338,0 MHz
SD	KIKA	frei	S 25	338,0 MHz
SD	ZDF	frei	S 25	338,0 MHz
SD	ZDF info	frei	S 25	338,0 MHz
SD	ZDF neo	frei	S 25	338,0 MHz
SD	ARTE	frei	S 31	386,0 MHz
SD	One	frei	S 31	386,0 MHz
SD	Phoenix	frei	S 31	386,0 MHz
SD	Tagesschau 24	frei	S 31	386,0 MHz
SD	Bayerisches FS Nord	frei	S 32	394,0 MHz
SD	Bayerisches FS Süd	frei	S 32	394,0 MHz
SD	Das Erste	frei	S 32	394,0 MHz
SD	HR FS	frei	S 32	394,0 MHz
SD	SWR FS BW	frei	S 32	394,0 MHz
SD	WDR FS Köln	frei	S 32	394,0 MHz
SD	MDR FS Sachsen	frei	S 33	402,0 MHz
SD	MDR FS Sachsen-Anhalt	frei	S 33	402,0 MHz
SD	MDR FS Thüringen	frei	S 33	402,0 MHz
SD	NDR FS Hamburg	frei	S 33	402,0 MHz
SD	NDR FS Mecklenb.-Vorp.	frei	S 33	402,0 MHz
SD	NDR FS Niedersachsen	frei	S 33	402,0 MHz
SD	NDR FS Schleswig-Holst.	frei	S 33	402,0 MHz
SD	RBB Berlin	frei	S 33	402,0 MHz
SD	RBB Brandenburg	frei	S 33	402,0 MHz
SD	SWR FS Rheinland-Pfalz	frei	S 33	402,0 MHz
SD	Al Rafiden	frei	S 38	442,0 MHz
SD	RIT TV/ Brasilien	frei	S 38	442,0 MHz
SD	Shant TV	frei	S 38	442,0 MHz
SD	Persian Toon	frei	S 38	442,0 MHz
SD	Persian Music Channel	frei	S 38	442,0 MHz
SD	TG Norba 24	frei	S 38	442,0 MHz
SD	Radionorba TV	frei	S 38	442,0 MHz
SD	Family TV	frei	K 25	506,0 MHz
SD	Zee One	frei	K 25	506,0 MHz
SD	Comedy Central / Nick	frei	K 29	338,0 MHz
SD	Viva Deutschland	frei	K 29	338,0 MHz
SD	Beauty TV	frei	K 30	546,0 MHz
SD	Channel 21	frei	K 30	546,0 MHz
SD	Deluxe Music	frei	K 30	546,0 MHz
SD	Hope Channel Deutsch	frei	K 30	546,0 MHz
SD	JML Direct Shop	frei	K 30	546,0 MHz
SD	MediaShop	frei	K 30	546,0 MHz
SD	Rhein-Neckar FS	frei	K 30	546,0 MHz
SD	EuroNews	frei	K 31	554,0 MHz
SD	Eurosport Germany	frei	K 31	554,0 MHz
SD	HSE 24 Extra	frei	K 31	554,0 MHz
SD	Bibel TV	frei	K 32	562,0 MHz
SD	QVC Deutschland	frei	K 32	562,0 MHz
SD	QVC Plus	frei	K 32	562,0 MHz
SD	Genius Plus TV	frei	K 35	586,0 MHz
SD	Sophia TV	frei	K 35	586,0 MHz

Pay-TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
HD	TNT Serie HD	sky	S 39	450,0 MHz
HD	TNT Serie HD	sky	S 39	450,0 MHz
HD	Universal Channel Dtschl. HD	sky	S 26	346,0 MHz
HD	Deluxe Music HD	Sky/HD+	K 34	578,0 MHz
HD	Disney Channel HD Germany	Sky/HD+	K 36	578,0 MHz
SD	Blue Movie Info	sky	S 28	362,0 MHz
SD	Discovery Channel Deutschland	sky	S 28	362,0 MHz
SD	Discovery Channel Deutschland	sky	S 28	362,0 MHz
SD	Jukebox	sky	S 28	362,0 MHz
SD	MGM Channel Deutschland	sky	S 28	362,0 MHz
SD	Nat Geo Channel Deutschland	sky	S 28	362,0 MHz
SD	RTL Crime	sky	S 28	362,0 MHz
SD	Sky Atlantic	sky	S 28	362,0 MHz
SD	Sky Bundesliga 1	sky	S 28	362,0 MHz
SD	Sky Cinema	sky	S 28	362,0 MHz
SD	Sky Emotion	sky	S 28	362,0 MHz
SD	Sky Krimi	sky	S 28	362,0 MHz
SD	Sky Nostalgie	sky	S 28	362,0 MHz
SD	Sky Select	sky	S 28	362,0 MHz
SD	Sky Sport 1	sky	S 28	362,0 MHz
SD	Sky Sport News	sky	S 28	362,0 MHz
SD	Beate Uhse TV	sky	S 29	370,0 MHz
SD	Classica Deutschland	sky	S 29	370,0 MHz
SD	Disney Junior Deutschland	sky	S 29	370,0 MHz
SD	Disney XD Deutschland	sky	S 29	370,0 MHz
SD	Junior	sky	S 29	370,0 MHz
SD	Sky Action	sky	S 29	370,0 MHz
SD	Sky Bundesliga 10	sky	S 29	370,0 MHz
SD	Sky Bundesliga 2	sky	S 29	370,0 MHz
SD	Sky Bundesliga 3	sky	S 29	370,0 MHz
SD	Sky Bundesliga 4	sky	S 29	370,0 MHz
SD	Sky Bundesliga 5	sky	S 29	370,0 MHz
SD	Sky Bundesliga 6	sky	S 29	370,0 MHz
SD	Sky Cinema +1	sky	S 29	370,0 MHz
SD	Sky Cinema +24	sky	S 29	370,0 MHz
SD	Sky Comedy	sky	S 29	370,0 MHz
SD	Sky Select 1	sky	S 29	370,0 MHz
SD	Sky Select 2	sky	S 29	370,0 MHz
SD	Sky Select 3	sky	S 29	370,0 MHz
SD	Sky Select 4	sky	S 29	370,0 MHz
SD	Sky Select 5	sky	S 29	370,0 MHz
SD	Sky Select 6	sky	S 29	370,0 MHz
SD	Sky Sport 11	sky	S 29	370,0 MHz
SD	Sky Sport 3	sky	S 29	370,0 MHz
SD	Sky Sport 4	sky	S 29	370,0 MHz
SD	Sky Sport 5	sky	S 29	370,0 MHz
SD	Sky Sport 6	sky	S 29	370,0 MHz
SD	Sky Sport 7	sky	S 29	370,0 MHz
SD	13th Street Deutschland	sky	S 30	378,0 MHz
SD	Blue Movie 1	sky	S 30	378,0 MHz
SD	Blue Movie 2	sky	S 30	378,0 MHz
SD	Blue Movie 3	sky	S 30	378,0 MHz
SD	Disney Cinemagic Deutschland	sky	S 30	378,0 MHz
SD	Fox Deutschland	sky	S 30	378,0 MHz
SD	GoldStar TV	sky	S 30	378,0 MHz
SD	Heimatkanal	sky	S 30	378,0 MHz
SD	Motorvision TV	sky	S 30	378,0 MHz
SD	Nat Geo Wild Deutschland	sky	S 30	378,0 MHz

Radio-Sender				
Radio Art	Sender	Kanal	Frequenz	
Radio	WDR 4	frei		S 24
Radio	WDR 5	frei		S 24
Radio	WDR Event	frei		S 24
Radio	You FM	frei		S 24
Radio	Deutschlandfunk	frei		S 25
Radio	Deutschlandradio Kultur	frei		S 25
Radio	Dokumente und Debatten	frei		S 25
Radio	DRadio Wissen	frei		S 25
Radio	Antenne Bayern	frei		K 30
Radio	ERF Plus	frei		K 30
Radio	Rock Antenne	frei		K 30
Radio	Sunshine Live	frei		K 30
Radio	DomRadio	frei		K 45
Radio	Ego FM	frei		K 45
Radio	Hope Radio	frei		K 45
Radio	Jam FM New Music Radio	frei		K 45
Radio	Klassik Radio	frei		K 45
Radio A	on3-Radio	frei		100,05MHz
Radio A	RTL Radio	frei		101,35MHz
Radio A	Radio Galaxy Bamberg	frei		101,65MHz
Radio A	Klassik Radio	frei		102,10MHz
Radio A	Rock Antenne	frei		103,65MHz
Radio A	MDR Figaro	frei		104,70MHz
Radio A	MDR Thüringen	frei		105,55MHz
Radio A	JUMP	frei		105,85MHz
Radio A	D Kultur	frei		106,80MHz
Radio A	Landeswelle Thüringen	frei		107,55MHz
Radio A	Deutschlandfunk, DLF	frei		87,65MHz
Radio A	Radio Horeb	frei		88,10MHz
Radio A	SWR 1	frei		88,70MHz
Radio A	SWR 2	frei		89,00MHz
Radio A	hr1	frei		90,05MHz
Radio A	NDR 2	frei		90,50MHz
Radio A	NDR Kultur	frei		90,80MHz
Radio A	Radio Paloma	frei		92,25MHz
Radio A	ERF	frei		92,55MHz
Radio A	Bayern 1	frei		93,60MHz
Radio A	Bayern 2	frei		94,45MHz
Radio A	Bayern 3	frei		95,00MHz
Radio A	Bayern 4 Klassik	frei		95,70MHz
Radio A	B5 aktuell	frei		96,65MHz
Radio A	Radio Bamberg	frei		97,00MHz
Radio A	Antenne Bayern	frei		97,75MHz
Radio A	SWR 3	frei		98,65MHz
Radio A	sunshine live	frei		99,15MHz

Frei empfangbare und HD+ TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
SD	Dr. Dish TV	frei	K 38	610,0 MHz
SD	Hochanda	frei	K 38	610,0 MHz
SD	TecTime TV	frei	K 38	610,0 MHz
SD	N-TV	frei	K 43	650,0 MHz
SD	RTL	frei	K 43	650,0 MHz
SD	RTL 2	frei	K 43	650,0 MHz
SD	RTL Nitro	frei	K 43	650,0 MHz
SD	RTL Nord	frei	K 43	650,0 MHz
SD	RTL West	frei	K 43	650,0 MHz
SD	Super RTL	frei	K 43	650,0 MHz
SD	Vox	frei	K 43	650,0 MHz
SD	a.tv (Augsburg TV)	frei	K 44	658,0 MHz
SD	Donau TV	frei	K 44	658,0 MHz
SD	Franken Fernsehen	frei	K 44	658,0 MHz
SD	INTV	frei	K 44	658,0 MHz
SD	Isar TV	frei	K 44	658,0 MHz
SD	München TV	frei	K 44	658,0 MHz
SD	Regio TV Schwaben	frei	K 44	658,0 MHz
SD	RFO	frei	K 44	658,0 MHz
SD	TRP 1	frei	K 44	658,0 MHz
SD	TV Allgäu	frei	K 44	658,0 MHz
SD	TV Oberfranken	frei	K 44	658,0 MHz
SD	TV Touring (Mainfranken TV)	frei	K 44	658,0 MHz
SD	TVA Ostbayern	frei	K 44	658,0 MHz
SD	Oberpfalz TV	frei	K 44	658,0 MHz
SD	1-2-3 TV	frei	K 45	666,0 MHz
SD	Anixe	frei	K 45	666,0 MHz
SD	Babestation 24	frei	K 45	666,0 MHz
SD	Disney Channel Deutschland	frei	K 45	666,0 MHz
SD	EWTN Katholisches FS	frei	K 45	666,0 MHz
SD	ManouLenz TV	frei	K 45	666,0 MHz
SD	QVC Beauty & Style	frei	K 45	666,0 MHz
SD	QVC Deutschland	frei	K 45	666,0 MHz
SD	Sixx	frei	K 45	666,0 MHz
SD	Sparhandy TV	frei	K 45	666,0 MHz
SD	TLC Germany	frei	K 45	666,0 MHz
SD	Astro TV	frei	K 46	674,0 MHz
SD	DMAX Deutschland	frei	K 46	674,0 MHz
SD	Ebru TV Europe	frei	K 46	674,0 MHz
SD	Equi 8 TV	frei	K 46	674,0 MHz
SD	HSE 24	frei	K 46	674,0 MHz
SD	HSE 24 Trend	frei	K 46	674,0 MHz
SD	MediaShop	frei	K 46	674,0 MHz
SD	Mediaspar TV	frei	K 46	674,0 MHz
SD	Mein TV Shop	frei	K 46	674,0 MHz
SD	Regio TV	frei	K 46	674,0 MHz
SD	Sonnenklar TV	frei	K 46	674,0 MHz
SD	Sport 1	frei	K 46	674,0 MHz
SD	Tele 5	frei	K 46	674,0 MHz
SD	Kabel Eins Deutschland	frei	K 47	682,0 MHz
SD	N 24	frei	K 47	682,0 MHz
SD	Pro Sieben	frei	K 47	682,0 MHz
SD	Pro Sieben Maxx	frei	K 47	682,0 MHz
SD	Sat. 1 Bayern	frei	K 47	682,0 MHz
SD	Sat. 1 Deutschland	frei	K 47	682,0 MHz
SD	Sat. 1 Gold	frei	K 47	682,0 MHz
SD	Sat. 1 NRW	frei	K 47	682,0 MHz
SD	Kabel Eins Classics	frei	K 47	682,0 MHz

Pay-TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
SD	Sky Bundesliga 7	sky	S 30	378,0 MHz
SD	Sky Bundesliga 8	sky	S 30	378,0 MHz
SD	Sky Bundesliga 9	sky	S 30	378,0 MHz
SD	Sky Hits	sky	S 30	378,0 MHz
SD	Sky Select 7	sky	S 30	378,0 MHz
SD	Sky Select 8	sky	S 30	378,0 MHz
SD	Sky Select 9	sky	S 30	378,0 MHz
SD	Sky Sport 10	sky	S 30	378,0 MHz
SD	Sky Sport 2	sky	S 30	378,0 MHz
SD	Sky Sport 8	sky	S 30	378,0 MHz
SD	Sky Sport 9	sky	S 30	378,0 MHz
SD	Sky Sport Austria	sky	S 30	378,0 MHz
SD	Spiegel Geschichte	sky	S 30	378,0 MHz
SD	Syfy Deutschland	sky	S 30	378,0 MHz
SD	TNT Serie	sky	S 30	378,0 MHz
SD	TNT Film	sky	S 41	466,0 MHz
SD	A&E Deutschland	sky	K 25	338,0 MHz
SD	AXN Deutschland	sky	K 25	338,0 MHz
SD	Kinowelt TV	sky	K 25	338,0 MHz
SD	Romance TV Deutschland	sky	K 25	338,0 MHz
SD	RTL Living	Sky	K 43	650,0 MHz
SD	Animax Deutschland/ England	Kabelkios	S 36	426,0 MHz
SD	Bon Gusto/ Deutschland	Kabelkios	S 36	426,0 MHz
SD	Euro News Deutsch	Kabelkios	S 36	426,0 MHz
SD	Euro News English	Kabelkios	S 36	426,0 MHz
SD	Euro News French	Kabelkios	S 36	426,0 MHz
SD	Euro News Italien	Kabelkios	S 36	426,0 MHz
SD	Euro News Portugese	Kabelkios	S 36	426,0 MHz
SD	Euro News Russia	Kabelkios	S 36	426,0 MHz
SD	Euro News Spanien	Kabelkios	S 36	426,0 MHz
SD	Euro Star/ Türkei	Kabelkios	S 36	426,0 MHz
SD	Kinowelt TV/ Deutschland	Kabelkios	S 36	426,0 MHz
SD	ORT International (Perviy kanal Vsemirnaja)	Kabelkios	S 36	426,0 MHz
SD	Marco Polo TV Germany	Kabelkios	S 36	426,0 MHz
SD	Stingray Lite TV	Kabelkios	S 36	426,0 MHz
SD	RTR Planeta/ Rußland	Kabelkios	S 36	426,0 MHz
SD	Samanyolu TV AVRUPA	Kabelkios	S 36	426,0 MHz
SD	ATV Avrupa/ Türkei	Kabelkios	S 37	434,0 MHz
SD	Euro D/ Türkei	Kabelkios	S 37	434,0 MHz
SD	Kanal 7 Avrupa/ Türkei	Kabelkios	S 37	434,0 MHz
SD	Mediasat Italia/ Italien	Kabelkios	S 37	434,0 MHz
SD	NTV Avrupa/ Türkei	Kabelkios	S 37	434,0 MHz
SD	Rai 1/ Italien	Kabelkios	S 37	434,0 MHz
SD	Rai 3/ Italien	Kabelkios	S 37	434,0 MHz
SD	Show Türk/ Türkei	Kabelkios	S 37	434,0 MHz
SD	TRT Türk/ Türkei	Kabelkios	S 37	434,0 MHz
SD	TV Polonia/ Polen	Kabelkios	S 37	434,0 MHz
SD	Detski Mir/ Rußland	Kabelkios	S 38	442,0 MHz
SD	Nashe Kino/ Rußland	Kabelkios	S 38	442,0 MHz
SD	RTV International/ Rußland	Kabelkios	S 38	442,0 MHz
SD	Teleklub/ Rußland	Kabelkios	S 38	442,0 MHz

Radio-Sender			
Radio Art	Sender	Kanal	Frequenz

Frei empfangbare und HD+ TV-Sender				
TV Art	Sender	frei/sky	Kanal	Frequenz
Analog	CNN	frei	S 06	140,25 MHz
Analog	One	frei	S 07	147,25 MHz
Analog	RTL 2	frei	S 08	154,25 MHz
Analog	n-tv	frei	S 09	161,25 MHz
Analog	Franken Sat mit TV Oberfranken	frei	S 10	168,25 MHz
Analog	Pro Sieben	frei	K 05	175,25 MHz
Analog	Sat.1	frei	K 06	182,25 MHz
Analog	ZDF	frei	K 07	189,25 MHz
Analog	Das Erste (ARD)	frei	K 08	196,25 MHz
Analog	Kabel Eins	frei	K 09	203,25 MHz
Analog	RTL	frei	K 10	210,25 MHz
Analog	Sport 1	frei	K 11	217,25 MHz
Analog	Bayerisches FS	frei	K 12	224,25 MHz
Analog	KI.KA	frei	S 11	231,25 MHz
Analog	VOX	frei	S 12	238,25 MHz
Analog	Phoenix	frei	S 13	245,25 MHz
Analog	Eurosport	frei	S 14	252,25 MHz
Analog	Disney Channel	frei	S 15	259,25 MHz
Analog	3 sat	frei	S 16	266,25 MHz
Analog	N 24	frei	S 17	273,25 MHz
Analog	Tele 5	frei	S 18	280,25 MHz
Analog	Servus TV	frei	S 19	287,25 MHz
Analog	Super RTL	frei	S 20	294,25 MHz
Analog	ARD-alpha	frei	S 21	301,25 MHz
Analog	HR 3	frei	K 21	471,25 MHz
Analog	MDR	frei	K 23	471,25 MHz
Analog	SWR BW	frei	K 22	479,25 MHz
Analog	DMAX	frei	K 24	487,25 MHz
Analog	Bloomberg TV	frei	K 27	519,25 MHz
Analog	NDR	frei	K 28	527,25 MHz
Analog	Nick / ComedyCentral	frei	K 40	623,25 MHz
Analog	WDR	frei	K 56	751,25 MHz
Analog	ZDF neo	frei	K 57	759,25 MHz
Analog	Sixx	frei	K 58	767,25 MHz
Analog	RBB	frei	K 59	775,25 MHz
Analog	ARTE	frei	K 60	783,25 MHz

Pay-TV-Sender					
TV Art	Sender	frei/sky	Kanal	Frequenz	

Radio-Sender				
Radio Art	Sender	Kanal	Frequenz	